




ASSA ABLOY

7100SZ Series SafeZone® External Sensor Installation and Instruction Manual

Patent Pending



Tools required:

- Allen wrench set (inch)
- Flat blade screwdriver (potentiometer & terminal size)
- Screwdriver (Phillips size 2)
- Tape rule
- Power drill
- Center punch
- Wire stripper



Table of Contents:

Mechanical Installation	2
Wiring Diagrams	3
Sensor Settings	4
Sensing Field Settings	5
Trouble Shooting	5
Specifications	6
Safety Precautions	6

Opening the sensor





ASSA ABLOY




Mechanical Installation

1. Apply adhesive backed template, supplied with sensor, to appropriate surface and aligned with centerline of door on side of opening opposite from SafeZone Mount.
2. Drill two 1/8" holes for mounting.
3. Drill one 1/4" hole for cable access.
4. Insert mounting screws into mount surface, but do not screw them fully in.
5. Route wiring through backplate.
6. Mount sensor backplate and tighten screws.
7. Complete wiring connections and sensor setup and testing.
8. Secure sensor cover to backplate.




Wiring Diagram
(Wiring external sensor to SafeZone Unit)
120VAC




Terminal	Connection
1 (Red)	24 VDC (+)
2 (Black)	24 VDC (-)
3 (White)	Relay Common
4 (Green)	Relay N.O.
5	Relay N.C.

Note: Input power tolerance is +/- 10% for AC, and -10% to +30% for DC power.

Wiring Diagram
(Wiring external sensor to SafeZone Unit)
24VDC



Sensor Settings



Hold Time

Hold open time is defined as the amount of time the door will remain open AFTER movement in opening is no longer detected.

Default Factory Settings:	
Sensitivity	3
Hold Time	10 seconds
Immunity	2
Detection Mode	1 (Bidirectional)
Door Control Mode	1

Setting Hold Open Time:

Press and release the Increase (+) or decrease (-) buttons until desired setting is achieved.

Reset Hold Time to Default:

Holding both buttons depressed simultaneously for 3 seconds will set unit at default hold time of 10 seconds.

Setting	Time (Seconds)
0	0.5
1	5
2	6
3	7
4	8
5 (Default)	10
6	14
7	16
8	18
9	20



Recommended Hold Time Settings

Sensitivity Setting

Sensitivity is factory set at setting #3. The sensitivity range is (0 - 9). This setting can be adjusted along with other advanced settings when using the optional remote.




Optional remote for advanced setting.
List number 7100REM

Sensing Field Adjustments

The position of the sensing field is determined by the vertical and lateral angle of the antenna.

Vertical Angle Adjustments




Sensing field as close to the door as possible:
Antenna is set at the position of 0°

Sensing field close to the door:
Antenna is set at the position of 30°

Sensing field far from the door:
Antenna is set at the position of 45°


Lateral Angle Adjustments



Nominal Detection Pattern with Sensor Set as follows:

Mounting Height:	7'-2"
Sensitivity:	3 (factory default)
Immunity:	2 (factory default)
Direction Mode:	1 (Bi-Directional; factory default)
Door Control:	1 (factory default)
Vertical Tilt:	30°
Lateral Tilt:	0°

Altering the lateral tilt angle will shift the detection pattern left or right of center.



Note:

Always “walk” the opening during sensor adjustment to confirm the detection pattern is adequate for the opening and application.

Adjusted hole open times as required for application.

See page 4 for hold open time settings.

Troubleshooting

SYMPTOMS	PROBABLE CAUSE	CORRECTIVE ACTION
Red LED does not light up. (No power to sensor)	Power switch is off. Loose wire connection.	Turn power switch to “ON” position. Inspect wiring for loose connections.
Door Stops several times in the same cycle without sensing presence in the door way.	Sensitivity is set too high	Change sensitivity setting using optional remote.
Door not closing when cover installed.	Eye is sensing the closer cover.	Adjust the sensing field away from cover edge. (See “Sensing Field Adjustments” above.

Sensor Technical Specifications

DESCRIPTION	SPECIFICATION
Frequency:	24.125 GHz
Supply voltage:	24 VDC: -10% / +30%:
Mounting height:	Normal: 7'; Maximum: 10'-0"
Tilt angle:	0° to 90° vertical -15° to +15° lateral
Detection area:	
Wide	13ft (W) x 6.5ft (D)
Narrow	6.5ft (W) x 8.2ft (D) (supplied as optional)
Minimum detection speed:	2 in/sec. (measured in axis)
Power consumption:	< 2 W
Standard output relay:	
Max contact voltage	60 VDC / 125 VAC
Max contact current	1 A (resistive)
Max switching power	30W (DC) / 60VA (AC)
Hold time:	0.5 sec. to 9 sec. (adjustable)
Temperature range:	-4°F to 131°F
Dimensions:	4.75in (W) x 3.15in (H) x 2.0in (D)
Weight:	0.5lbs
Material:	ABS

Safety Precautions

- Shut off all power going to the header before attempting any wiring procedures.
- Maintain a clean & safe environment when working in public areas.
- Constantly be aware of pedestrian traffic around the door area.
- Always stop pedestrian traffic through the doorway when performing tests that may result in unexpected reactions by the door.
- Always check placement of all wiring and components before powering up to ensure that moving door parts will not catch any wires and cause damage to equipment.
- Ensure compliance with all applicable safety standards upon completion of installation.

ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS



Circuit board components are vulnerable to damage by electrostatic discharge (ESD). ESD can cause immediate or subtle damage to sensitive electronic parts. An electrostatic charge can build up on the human body and then discharge when you touch a board. A discharge can be produced when walking across a carpet and touching a board, for example. Before handling any board, make sure you dissipate your body's charge.

CAUTION: In the event a unit needs to be opened, observe the following precautions.

- Ground yourself by touching a conductive surface of the door or other element connected to common earth ground to discharge the static electricity present in your body.
- Avoid walking around while replacing items inside the case, especially if you are on carpet or during conditions of low temperature and low humidity.
- Handle the board by the edges only to avoid touching electronic components.
- Store a loose board in an anti-static bag.

Norton

ASSA ABLOY

3000 Highway 74 East • Monroe, NC 28112
Tel: (877)-974-2255 • Fax: (800)-338-0965
www.nortondoорcontrols.com