




Installation Instructions:

1. Pivot point determined by bottom pivot or floor closer.
2. Prepare door and frame per details shown.
3. To insure proper operation of door, the centerline of the top pivot pin must be straight and plumb with bottom spindle.
4. Install walking beam with pin retracted.
5. Install 102 portion.
6. Place door on bottom pivot and raise door to vertical position.
7. Engage top pivot pin by turning adjusting screw clockwise when door portion is in alignment with the jamb portion.

Notes:

1. Do not scale drawing.
2. Dimensions are given in inches (mm).
3. Centerline may vary. See bottom pivot or floor closer for its centerline.

320 x 102 Top Pivot Center Hung Non Handed

RIXSON®
ASSA ABLOY

www.rixson.com

TEMPLATE NUMBER

IS-320x102

DATE

07-09