




07-09

# 117 X 1-1/2 Pivot Set




## 1. LOCATE PIVOT

- Measure 13/16 (20.6) from door jamb.
- Allow 1/8 (3.2) minimum clearance from door stop to door face. Measure door thickness; add 3/4 (19).
- Where lines meet determines centerline of pivot.




## 2. SET PIVOT SET

- Prepare floor to receive Floor Portion. Set anchors provided securely in floor.
- IMPORTANT:** Floor Portions must be level. Level in both directions per illustration.
- Floor Portion should be parallel with face of door.



## 3. INSTALL TOP PIVOT AND PIVOT ARM.

- Install top pivot in door per template.
- Install top pivot in frame per template.
- Install arm in door per template.
- Centerline of top pivot should line up with centerline of spindle.
- If side jamb pivot is used, see required template, T-M19-1-1/2.



## 4. HANG DOOR

- Set door on Floor Portion.
- Push top pivot pin (1) up into place and replace cap (2)..
- Put arm cap on arm and secure tightly with screw furnished.

Do Not Scale Drawing

117 Pivot Set  
 1-1/2" Offset, Handed

**RIXSON®**  
**ASSA ABLOY**  
 www.rixson.com

TEMPLATE NUMBER	DATE
IS117 1-1/2	07-09