



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION GUIDE

Installation Guide - Single Cylinder Deadbolts

EMTEK
ASSA ABLOY

1. Door Prep <p>2 1/4" or 2 3/4" Backset 1/4" Deep 2 1/4" 2 1/2" Diameter Bore 1" Diameter Edge Bore 1"</p>	Install Deadbolt on regular door. <p>Door Thickness: 1 1/4" - 2 1/4" Tail Piece Horizontal</p>
2. Door Jamb Prep <p>1/4" Deep 1 1/4" From Door Face 1 1/4" 2 1/4" 1 1/4" 1 1/4"</p>	Install Deadbolt on thin door. Extension Ring is provided for the following products: 8454, 8466, 8468, 8458, 8459, 8467, 8469, 8475 <p>Door Thickness: 1 1/2" - 1 3/4" Extension Ring Tail Piece Horizontal</p>
3. Install Latch <p>Crosshairs at bottom.</p>	5. Inside Installation <p>Door Thickness: 1 1/4" - 1 1/2" Extension Collar Tail Piece Horizontal</p>

EN4 DEADBOLT/ENICE 04-25-2011



www.tmhardware.com



845-388-1300



845-388-1388



sales@tmhardware.com