



**TRADEMARK  
HARDWARE**

WORLD OF QUALITY HARDWARE

## INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, 7/64" drill bit, Phillips screwdriver and pencil.

1. Position plate 3/4" from edge of door and approximately 50" from bottom of door to center of plate.
2. Mark, drill and secure.

