



**TRADEMARK  
HARDWARE**

WORLD OF QUALITY HARDWARE

## **DOOR EDGE PULL**

FOR USE ON POCKET SLIDING DOORS

### **INSTALLATION INSTRUCTIONS**

**TOOLS REQUIRED:** Phillips screwdriver, drill, 3/32" drill bit for pilot holes, hammer, small chisel and pencil.

1. Position in center of door edge approximately 40"-42" from bottom of door, with pull handle facing out. Mark outside shape and screw hole locations.
2. Mortise door edge to fit plate and pull handle in position. (See illustration A for cutout dimensions).
3. Drill, position and secure.

