



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, 3/8" and 3/32" drill bits, hammer, small chisel and Phillips screwdriver.

1. Position template on top or bottom center of door edge.
2. Outline and mortise (A) 1/16" deep.
3. Using template, mark screw holes, outline section B, mortise 3/4" deep, and secure bolt.
4. Rub chalk on end of bolt, close door and push lever up to mark strike hole position.
5. Outline strike plate, mortise area 1/16" deep, drill strike hole (C) 1" deep with 3/8" bit; align strike and secure.

