



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, 7/64" drill bit for pilot holes, small chisel, Phillips screwdriver and pencil.

FOR DUTCH DOOR APPLICATION -

1. Position bolt approximately 2" - 3" from edge of door. Using dimensions in illustration (A) mark, drill and secure.
2. Position standard strike at top of bottom door aligned with bolt. Trace bottom portion of strike (section with 2 screw holes). Mortise this area ONLY - to depth of 1/8" Position strike, mark, drill and secure.

FOR STANDARD DOOR APPLICATION -

1. Mount bolt at top of door following instructions above #1.
2. Position universal strike to align with bolt on upper door jamb as shown in illustration (B). Mark, drill and secure.

