



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, $\frac{1}{16}$ " drill bit, Phillips screwdriver, awl or pencil.

1. Position case (A) on cabinet, as shown, or at point where door inset fits into cabinet. Mark, drill pilot holes at center point of elongated holes and secure.
2. Position strike (B) on inside door to align with case (A). Mark, drill pilot hole and secure.
3. To assure snug closing make adjustment by moving case (A) either outward or inward and secure.

