



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, 3/32" and 9/16" drill bits, chisel, hammer, Phillips screw-driver and pencil.

1. Position in center of door edge in desired location. Mark and drill 9/16" dia. hole 1" deep (A).
2. Position catch in hole — mark screw holes and shape of plate. Remove catch. Drill 3/32" pilot holes for screws and chisel out plate area 1/16" deep. Secure.
3. Locate strike as shown in (B) to align with ball catch (curved edge facing out). Mark screw holes and shape of strike.
4. Mortise out area 3/8" x 1/2" x 3/16" deep to accommodate inverted catch section of strike (C). Chisel shape of strike to 1/16" deep. Secure.
5. Adjust ball clearance by turning threaded area (D).

