



**TRADEMARK  
HARDWARE**

WORLD OF QUALITY HARDWARE

## INSTALLATION INSTRUCTIONS

**TOOLS REQUIRED:** Phillips screwdriver, awl or pencil.

1. Position catch (A) on inside of door approximately 1/2" from edge. Mark and secure loosely.
2. Position strike (B) to line up with catch. Mark and secure loosely.
3. Check alignment of catch and strike before securing tightly.

