



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, $\frac{1}{16}$ " and $\frac{1}{8}$ " drill bits, Phillips screwdriver, hammer, awl or pencil.

1. Open door into desired stop position.
2. Slide template under door and tape to floor.
3. Mark hole centers.
4. Drill stud hole approximately 1" deep with $\frac{1}{16}$ " drill bit. For wood floors, drill screw hole 1" deep with $\frac{1}{8}$ " drill bit. For concrete floors, drill screw hole 1" deep with $\frac{1}{16}$ " drill bit.
5. Secure stop into position. For concrete floors, insert plastic screw anchor before securing stop.

