



**TRADEMARK  
HARDWARE**

WORLD OF QUALITY HARDWARE

## INSTALLATION INSTRUCTIONS

**TOOLS REQUIRED:** Pencil.

1. Apply at room temperature (approximately 60°F).
2. Clean surface, let dry.
3. Mark center point where door knob touches wall.
4. Remove protective backing, position in center of mark on wall and press firmly for good contact.

**NOTE:** Do not remove to reposition.

