



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, 9/16" drill bit, screwdriver and pencil.

1. Position at eye level in center of door. Mark and drill 9/16" dia. hole completely through door.
2. Place receiver tube section (A) through inside of door.
3. Insert section (B) from outside of door and secure into section (A).

