



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, 1/2" drill bit, screwdriver and pencil.

1. Position at eye level in center of door. Mark and drill 1/2" dia. hole completely through door.
2. Place receiver tube section (A) through washer (B) and insert through hole from inside of door.
3. Insert section (C) from outside of door and secure into section (A).

