



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, 1/4" and 1/2" drill bits, awl and screwdriver.

1. Position template (right) centered from side to side 60" above threshold. Tape template to outside of door.
2. Mark centers with awl (or nail) and drill holes (A) with 1/4" drill bit completely through door.
3. Drill hole (B) for viewer with 1/2" drill bit completely through door from outside.
4. Mount door knocker with screws and cover washers.
5. Insert viewer (C) through knocker from outside. Insert receiver tube (D) from inside and tighten. See illustration.

