



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Stud finder, Phillips screwdriver, drill, $\frac{1}{8}$ " and $\frac{5}{32}$ " drill bits, pencil

1. Draw a line parallel to staircase at height of 30".
2. Locate studs in wall and install brackets in vertical position equally spaced using $\frac{5}{32}$ " drill bit. Mark and drill pilot holes with $\frac{1}{8}$ " drill bit in handrail.
3. Secure rail clamps to bottom side of rail as illustrated.

