



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, 1/8" drill bit, Phillips screwdriver, awl or pencil.

1. Place in desired position and mark.
2. Drill pilot holes and secure with screws provided.

