



INSTALLATION INSTRUCTIONS

TOOLS REQUIRED:

Drill, $\frac{3}{32}$ " drill bit,
Phillips screwdriver, awl
or pencil.

1. Place window lock flat on window frame (A) in retracted position $\frac{1}{16}$ " away from window rail (B) and approximately 6" from window sill.
2. Mark, drill pilot holes and secure.

NOTE: Two side window locks are recommended per window.

