



**TRADEMARK  
HARDWARE**

WORLD OF QUALITY HARDWARE

## **INSTALLATION INSTRUCTIONS**

**TOOLS REQUIRED:** Phillips screwdriver, pencil and awl.

### **FOR WINDOW APPLICATION -**

1. Position pull on center of rail of lower window. Mark and secure. (If 2 used, space equally).

### **FOR PULL APPLICATION -**

1. Place in desired vertical position. Mark and secure.

