

Installation Guide - Ball Catch



EMTEK

Door Prep	Install Strike Plate	Install Ball Catch
7/8" DIA. EDGE BORE 1-1/2" DEEP 1" 1 33/64" 2 1/8" 1/16" DEEP	Install Strike Plate	Install Ball Catch
Door Jamb Prep		
3/16" DEEP RELIEF 1" 1 33/64" 2 1/8" 1/16" DEEP		

Installation Instructions - Roller Catch



EMTEK

Door Prep	Install Strike Plate	Install Roller Catch
1 5/8" DEEP 1" 2 5/16" 3 3/8" 2 7/8" 1/4" DEEP	Install Strike Plate	Install Roller Catch
Door Jamb Prep		
1 1/2" 1" 2 1/4" 1 1/16" 5/32" DEEP		