
PFT-62 Sidelite Transom Patch Fitting w/Stop Installation Instructions




ASSA ABLOY

The global leader in door opening solutions

For Installation Assistance, Call 855.594.6989 • www.assaabloyglass.us



Parts Included




PFT-62 Parts List	
1	Cover Plate
2	Bracket
3	Bushings (3)
4	Bracket
5	1 ¹ / ₁₆ " - M6 x 27 Screws (3)
6	Cover Plate

1. Prepare the Glass

USE FABRICATION SKETCH TO DRILL GLASS.

• Drill three $^{13}/_{16}$ " (20 mm) diameter holes.

NOT TO SCALE DIMENSIONS IN INCHES (MILLIMETERS)




Caution: Office copiers, printers and facsimile machines may change the size of a drawing and make it inaccurate to use as a template.

2. Fasten Support Brackets


Make sure the surface is thoroughly cleaned and remove all screws.

- Insert the three Bushings 3 into prepped 13/16" (20 mm) diameter holes.
- Place Bracket 2 into prepped area of glass, join Bracket 4 from the other side. Insert Screw 5 into Bracket 2 and tighten with 5 mm hex wrench to hold Brackets together. Do not tighten completely to allow for adjustments throughout installation.
- Insert two Screws 5 into Bracket 4, align fitting to desired position. Torque both Screws to 12 nm. Then tighten Bracket 2 Screw to 12 nm.



3. Adhere Cover Plates

- Remove adhesive strip paper on both Brackets (2, 4) to adhere Cover Plates 0 & 6.
- Hook Cover Plates **1** & **6** over hinge side locking pins.
- Push in spring loaded locking pin on opposite side of Bracket.
- Snap on Cover Plates.



ASSA ABLOY

ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience



www.assaabloyglass.us

USA: ASSA ABLOY Glass Solutions Rockwood, PA 15557 Phone: 855.594.6989