



**TRADEMARK  
HARDWARE**

WORLD OF QUALITY HARDWARE

# INSTALLATION GUIDE

## *Tools Required:*



## *Installation Instructions:*

1. To install, door must be removed.
2. Measure, mark and trim door bottom shoe to full width of door. Trim seal 1/16' longer than trimmed door shoe at each end.
3. Remove vinyl.
4. Fasten door bottom shoe to bottom of door with supplied screws.
5. Replace vinyl. Crimp ends to secure insert.

