




**Trademark
HARDWARE**

INSTALLATION GUIDE

Tools Required:



Installation Instructions:



↑
**Covers
Floor
Seams**

1. Measure length of seam to be covered.
2. Measure, mark and trim product to length using tin snips or hacksaw.
3. Place product over seam and screw in place:
 - a. Wood floor installation: secure to floor with supplied screws.
 - b. Concrete floor installation: secure to floor using rawl pugs (rawl plugs not included).