



**Trademark
HARDWARE**

INSTALLATION GUIDE

Door Bottom Sweep, PemkoPrene™ or Vinyl 1"

Tools Required:



Installation Instructions:

1. Measure, mark, & trim door bottom sweep to full width of door. Trim seal to 1/16" longer than the trimmed housing (profile) on each end.
2. Close door and position door bottom sweep along outside bottom edge of door so that it makes light even contact with threshold. Mark door in center of slotted holes.
3. Drill pilot holes in door at marks.
4. Secure door bottom sweep to door with supplied screws. Adjust to ensure light even contact with threshold.