



Trademark
HARDWARE

INSTALLATION GUIDE

Tools Required:



Installation Instructions:

1. Measure, mark, & trim door bottom sweep to full width of door.
2. Close door and position door bottom sweep along outside bottom edge of door so that it makes light even contact with threshold. Mark door in center of slotted holes.
3. Drill pilot holes in door at marks.
4. Secure door bottom sweep to door with supplied screws. Adjust to ensure light even contact with threshold.