



**Trademark
HARDWARE**

INSTALLATION GUIDE

Tools Required:



Installation Instructions:

1. Trim 68_R to door width.
2. 347 overhead raindrip should be 2" wider than door at each side.
3. Position raindrip (347) even with bottom of head and fasten with screws provided.
4. Fasten door top (68) at top edge of door with screws provided.
5. Adjust to provide best seal and door closing.

