



**Trademark
HARDWARE**

INSTALLATION GUIDE

Brush Perimeter Gasket

Tools Required:



Installation Instructions:

CUTTING BRUSH:

1. Remove brush prior to cutting.
2. Trim off excess brush using Lineman Side Cutting Pliers and crimp the brush filament ends.
3. Re-insert the brush until it is flush with one end of the retainer and crimp to hold in place.

PERIMETER GASKETING:

1. Can be installed on a wood or metal frame.
2. Measure, mark and trim header piece to length. Close door and position header piece on header stop so that seal makes light even contact with door. Mark header stop in center of slotted holes.
3. Drill pilot holes in header stop at marks.
4. Secure header piece to header stop with supplied screws.
5. To install the 2 jamb pieces, repeat steps 2, 3, and 4. Jamb pieces should contact threshold (or floor) at bottom & contact header piece at top.
6. Open and close door several times to check jamb weatherstrip fit and seal, and to make sure latch bolt engages strike plate.
7. To adjust, loosen screws, re-position weatherstrip, and tighten screws.