



**Trademark
HARDWARE**

INSTALLATION GUIDE

Tools Required:



Installation Instructions:

1. Trim to length.
2. Install on the active leaf of pair of outswinging doors.
3. Position to cover the meeting stiles gap.
4. Fasten with screws or through bolts provided.