



**Trademark  
HARDWARE**

# INSTALLATION GUIDE

## *Tools Required:*



## *Installation Instructions:*

1. Trim to length.
2. Install on the active leaf of pair of outswinging doors.
3. Position to cover the meeting stiles gap.
4. Fasten with screws or through bolts provided.