



**Trademark
HARDWARE**

INSTALLATION GUIDE

Neoprene Door Bottom

Tools Required:



Installation Instructions:

1. Measure, mark and trim door bottom sweep to full width of the door.
2. Drill pilot holes in door at marks.
3. Mount to door with supplied fasteners.