



**Trademark
HARDWARE**

INSTALLATION GUIDE

Tools Required:



Installation Instructions:

1. Install astragal on push side of active door. With back of astragal $15/16$ " from edge of door, mark mounting holes.
2. Drill mounting holes and install with screws provided.
3. Locate operating cam as shown below, mark, drill and install cam with screws provided.
4. If cam does not hold astragal flush with face of door, loosen screws and rotate cam until it is flush.

Astragal is shown below in both open (left) and closed (right) positions.

