




**Trademark
HARDWARE**

INSTALLATION GUIDE

Tools Required:



Installation Instructions:

1. Can be installed on a wood or metal frame.
2. Measure, mark and trim piece to length. Close door and position so that seal makes light even contact with door. Mark in center of holes.
3. Drill pilot holes in stop at marks.
4. Secure piece to stop with supplied screws.
5. Open and close door several times to check jamb weatherstrip fit and seal.
6. Adjust the adjustment screw as necessary to fit seal properly.