



**Trademark  
HARDWARE**

# INSTALLATION GUIDE

## **End Plate Installation Instructions:**

**PLEASE READ THESE INSTRUCTIONS THOROUGHLY BEFORE ATTEMPTING TO INSTALL END PLATES.**

**IMPORTANT!** These parts are made from glass filled nylon. They are very strong, but brittle. Do not attempt to twist or bend them or they will break. This is not a problem if properly installed or removed.

1. The automatic door bottom must be correctly installed and adjusted in accordance with the installation instructions furnished with this product (see other side).
2. Be sure that the drop bar (part that contains the seal) does not project beyond the end of the case when the actuation plunger is depressed. If it does project beyond the case, it was improperly trimmed in the field. This condition can be corrected by removing the unit and trimming the excess.

**NOTE:** Under no condition should the insert project beyond the edge of the case.

3. Install the flat end cover plate on the lock edge of the door with the fasteners provided.