



**Trademark  
HARDWARE**

# INSTALLATION GUIDE

## Aluminum and Neoprene Door Bottom Sweep

### Door Sweeps INSTALLATION INSTRUCTIONS

- 1 Measure and cut sweep to fit.
- 2 Close door. Hold sweep making gentle contact with the threshold.
- 3 Mark screw holes. Drill holes using a 2.5mm drill bit.
- 4 Install with screws provided.
- 5 Adjust sweep position to make proper contact with the threshold, allowing smooth operation of the door.