




**Trademark  
HARDWARE**

# INSTALLATION GUIDE

## Mortised Door Bottom

### *Tools Required:*



### *Installation Instructions:*

1. Remove brush from aluminum retainer.
2. Cut aluminum retainer to desired length.
3. Cut brush insert to fit aluminum retainer.
4. Route a 1/4" by 1/4" groove into the face or edge you intend to install the aluminum retainer.
5. Insert metal retainer into routed out groove.  
**NOTE:** Secure retainer with a small brad at both ends of retainer for additional security if desired.
6. Slide the brush into the retainer.  
**NOTE:** Metal channel for brush should have a slight wave to its shape to help retain the brush from slipping out of the aluminum retainer.