



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

Installation Guide

- 1 Measure and cut threshold to size as required.
- 2 Notch as necessary, to suit door frame.
- 3 Caulk underneath and around edges of threshold for moisture control.
- 4 Attach threshold to floor surface with screws provided.

SKU: Z565



www.tmhardware.com



845-388-1300



845-388-1388



sales@tmhardware.com