TRADEMARK HARDWARE
WORLD OF QUALITY HARDWARE

Installation Instructions

1. Cut threshold to size required.
2. Notch around door frame if desired.
3. Attach to floor surface with fasteners provided.
4. Caulk around base of threshold for moisture control.