



**Trademark  
HARDWARE**

# INSTALLATION GUIDE

## Existing Construction Anchor Options

**WOOD OR MACHINE SCREWS, SILVER TAPCON SCREWS, or SCREW & SHIELDS**



WOOD or MACHINE  
SCREWS



SILVER TAPCON  
SCREWS



SCREW & SHIELDS

**Treads are furnished drilled and countersunk unless otherwise specified.**

**Recommended installation is stringer to stringer less 1/8" to 1" clearance each end (beveled ends not available).**

**Can be installed with only construction adhesive and no screws.**



**Wooster recommends Leveling Compound to fill/level worn steps before installing treads.**



**To install with screws just punch through top surface of FlexTred with screw point and install through pre-drilled and countersunk hole in aluminum.**