



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

Installation Guide

Installation Instructions

1. Cut seal to fit.
2. With door closed, position seal, Mark screw holes.
3. Drill pilot holes for screws using a 7/64" drill bit.
4. Install with screws provided in all mounting holes, working from one end to the other.
5. Adjust position so that gasket is slightly compressed against door but does not impede proper closing and latching.

**APPLICATION WARNING:
DO NOT DRILL THROUGH GASKETING MATERIAL.
DRILL BIT WILL DAMAGE MATERIAL.**

SKU: N120S



www.tmhardware.com



845-388-1300



845-388-1388



sales@tmhardware.com