




**Trademark  
HARDWARE**

# INSTALLATION GUIDE

## Tools Required:



## Installation Instructions:



↑  
**Trims  
Carpet  
Edge**

1. Measure length of carpet or seam to be covered.
2. Measure, mark and trim carpet bar to length using tin snips or hacksaw.
3. Place carpet bar over carpet or seam and nail in place:
  - a. Wood floor installation: secure to floor with supplied nails.
  - b. Concrete floor installation: secure to floor using rawl pugs (rawl plugs not included).