



**Trademark
HARDWARE**

INSTALLATION GUIDE

Tools Required:



Installation Instructions:

PERIMETER GASKETING:

1. Can be installed on a wood or metal frame.
2. Measure, mark and trim to length. Close door and position so that seal makes light even contact with door.
3. Drill pilot holes in stop at marks.
4. Secure with supplied screws.
5. Open and close door several times to check weatherstrip fit and seal.
6. To adjust, loosen screws, re-position weatherstrip, and tighten screws.
7. Snap on cover.

ASTRAGALS/MEETING STILES:

1. Trim lengths equal to door height.
2. Position at meeting stile edge of doors. Install screws in center of slots.
3. Adjust as required for proper seal, with ease of opening and closing, then tighten screws.
4. Snap on cover.