



## *Tools Required:*



## *Installation Instructions:*

### CUTTING BRUSH:

1. Remove brush prior to cutting.
2. Trim off excess brush using Lineman Side Cutting Pliers and crimp the brush filament ends.
3. Re-insert the brush until it is flush with one end of the retainer and crimp to hold in place.

### DOOR BOTTOMS:

1. To install, door must be removed.
2. Measure, mark and trim door bottom shoe to full width of door. Trim seal 1/16" longer than trimmed door shoe at each end.
4. Fasten door bottom shoe to bottom of door with supplied screws.

### MEETING STILES:

1. Measure, mark and trim lengths equal to door width.
2. Trim seal 1/16" longer than door at each end.
3. Remove insert.
4. Position at meeting stile edge of doors.
5. Install screws in center of slots.
6. Adjust as required for proper seal, with ease of opening and closing, then tighten screws.
7. Replace insert. Crimp ends to secure insert.