



**Trademark  
HARDWARE**

# INSTALLATION GUIDE

## **Tools Required:**



## **Installation Instructions:**

1. Measure, mark, and trim sill nosing to desired length. If necessary, trim (notch) around door jambs.
2. Secure using construction grade adhesive (or caulking) to bond metal nosing to concrete sill to be covered (adhesive not included).
3. If intended for use with pre-installed threshold, loosen threshold screws, slip top leg of nosing under outside leg of threshold and adhere as described in step 2.