



**Trademark
HARDWARE**

INSTALLATION GUIDE

Tools Required:



Installation Instructions:

1. Trim to length (equal to door height).
2. Install on meeting stile with screws provided.
3. Apply to active leaf of outswinging doors or inactive leaf of inswinging doors.