



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE


INSTALLATION GUIDE

Pemko H1100A-SW Sliding Door Hardware


door opening solutions

Door Leaf Capacity - Up to 1100 lbs.


Manufactured by
HENDERSON



Side Wall Mount



Part Number	Material	Track Length	Door Width
H1100A-SW/6	Aluminum	72"	36"
H1100A-SW/8	Aluminum	96"	48"
H1100A-SW/10	Aluminum	120"	60"
H1100A-SW/12	Aluminum	144"	72"
H1100A-SW/16	Aluminum	197"	98"



H1100A-SW Kits Include:

- 1 ea 550A Mill Finished Aluminum Track
- 1A/550 Aluminum Alloy Side Wall Track Bracket (One at each end and no more than three feet in between.) Fasteners not included.
- 2 ea 556/57 Painted Black Steel Body - Zinc Coated Steel Wheels and Pendant Bolt Hangers
- 2 ea HH3/301 Galvanized Steel In-Track Stop
- 1 ea 89/2N Gray Nylon Mortise Guide



www.tmhardware.com



845-388-1300



845-388-1388



sales@tmhardware.com



**TRADEMARK
HARDWARE**


WORLD OF QUALITY HARDWARE

INSTALLATION GUIDE

1. Secure track.


Secure track at each end. Inward brackets should be 2' (61m) from each end and centered on track.

Ensure track is plumb and level by adjusting (4) adjustable track screws provided with 1A/550 bracket.




2. Mortise door for door guide.

Attach a plumb line to hanger. Place hanger inside track. Using plumb line, mark the centerline of door guide.




3. Fit door guide to floor.



4. Prepare top of door for hanger hardware.

- 1 Drill $1\frac{3}{16}$ " (33.3) dia. x 2" (50.8) deep hole 6" (152.4) from door edge to centerline of hole and centered in thickness of door.
- 2 Route door for $\frac{1}{4}$ " (6.4) thick, $7\frac{5}{16}$ " (185.7) long, and $1\frac{1}{2}$ " (38.1) wide plate centered on centerline of hole and thickness of door.






**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION GUIDE


5. Attach hangers to doors.





*From door edge to centerline of hanger bolt and plate.

6. Hang door.

Slowly guide complete door unit into track using installed floor guide.



7. Position and secure clip stops.





**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION GUIDE

IMPORTANT:

Visually check all bolts and screws; tighten if necessary.

If access door is installed, check operation.

Check operation of doors for ease.

- Door catches floor guide: Check that the track is level. Ensure that the track and floor guide are parallel to within $\pm 1/8"$ (3).
- Door scrubs: Check that the door is level on hangers.
- Door moves while in operation: Check hangers are installed correctly.

