



**Trademark  
HARDWARE**

# INSTALLATION GUIDE

## Existing Construction Anchor Options

**WOOD OR MACHINE SCREWS, SILVER TAPCON SCREWS, or SCREW & SHIELDS**



WOOD or MACHINE  
SCREWS

SILVER TAPCON  
SCREWS

SCREW & SHIELDS

Drilled and countersunk holes are standard unless otherwise specified.

**Wooster recommends Leveling Compound to fill/level worn steps before installing Stairmaster® treads.**



**Use construction adhesive in addition to mechanical fasteners for the best installation results.**



**STAIRMASTER® ON CONCRETE STAIR, CUT TO FIT AROUND THE POST & THE LENGTH OF THE STAIR WITH SQUARE ENDS.**



**STAIRMASTER® ON WOOD STAIR, CUT SHORTER THAN THE LENGTH OF THE STAIR WITH BEVELED ENDS.**

**Trademark  
HARDWARE**

148 Horton Drive, Suite B  
Monsey, NY 10952

Phone: 845-388-1300  
Fax: 845-367-4657

[www.TMHardware.com](http://www.TMHardware.com)  
[sales@tmhardware.com](mailto:sales@tmhardware.com)