



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION GUIDE

- 1.** Measure door sill (frame width at bottom) and cut the threshold to extend the full width of the opening.
- 2.** Notch the threshold sides if necessary to accommodate the side jamb stops.
- 3.** Fasten on threshold to the sill with proper screws.
- 4.** Operate the door several times to ensure the threshold does not to inhibit the door from self-closing and latching.

