

TruSil 100 Silicone Sealant

Installation Guide

General Installation Guide

1. Thoroughly clean and dry desired area.
2. Cut tip off cartridge. Screw nozzle on end and cut tip to desired bead size. Insert cartridge into standard caulk gun.
3. Hold at 45° angle and apply by pushing sealant ahead of nozzle to achieve a smooth seal. Apply using a steady, even pressure to completely bridge joints.
4. Complete tooling within 5 minutes. Use dry paper towel to remove excess material. Smooth caulk using wet finger or a damp cloth for a clean, neat appearance.
5. Sealant normally “skins over” in 5 minutes, dries to touch in 1 hour, and cures & bonds in 24 hours. Allow 7 day cure time to reach maximum strength.

Installation Guide for Application onto Floor Barrier Channels

1. Insert TruSil Sealant into compatible caulking gun and prep as above. (Figure 1)
2. Apply 2 beads of sealant running along the back of the Floor Barrier Channel. (Figure 2)
3. Screw Flood Barrier Channel onto wall / door frame. (Figure 3)
4. Apply a bead of sealant running along each side of the applied Flood Barrier Channel. (Figure 4).

