Lever functions

| Catalog number | Function | Name | Description | ANSI no. |
|-------------------|----------|-----------------------------|---|----------|
| *W101 | | Passage/ closet set | Latch bolt by levers at all times. | F75 |
| *W161 | | Communicating/ exit lock | Deadlocking latch bolt by inside lever. Non-removable blank plate outside. Inside lever is always free. | |
| W201 | | Patio lock | Deadlocking latch bolt by levers. Outside lever is locked by push button from inside. Rotating inside lever or closing door releases button and unlocks outside lever. | F77 |
| *W301 | | Privacy lock | Latch bolt by levers. Outside lever is locked by push button on inside lever. Rotating inside lever or closing door releases push button and frees outside lever. Inside lever is always free. Emergency release in outside lever unlocks door. | F76 |
| W501 | | Entry lock | Push button locking. Button on inside locks outside lever until unlocked by key or by rotating inside lever. Closing door release push button and unlocks door. Inside lever always free. Deadlock latchbolt. | F82 |
| *W511 | | Entry/office lock | Deadlocking latch bolt by levers. Turn/push button locking. Pushing and turning button locks outside lever, requiring use of a key for unlocking the door until button is manually unlocked. Pushing button locks outside lever until unlocked by key or by rotating inside lever. Inside lever is always free. | F109 |
| *W561 | | Classroom lock | Deadlocking latch bolt by levers. Outside lever is locked by key in outside lever. Inside lever is always free. | F84 |
| *W571 | | Corridor lock | Deadlocking latch bolt. Push Button Locking. Button on the inside locks outside lever until unlocked by key or by rotating inside lever. Closing the door releases button. Inside lever always free. | |
| *W581 | | Storeroom lock | Deadlocking latch bolt by lever inside or key outside. Outside lever is always locked. Inside lever is always free. | F86 |
| W711 | | Apartment entrance lock | Deadlocking latch bolt by levers. Turn/push button locking. Pushing and turning button locks outside lever, requiring use of a key for unlocking the door until button is manually unlocked. Pushing button locks outside lever until unlocked by key, by rotating inside lever, or by closing the door. Inside lever is always free. | |
| *W12 | | Single dummy | Single trim, surface-mounted rigid lever. | |
| *W18 | | Double dummy | Double trim, surface-mounted rigid levers. | |

¹ This lock will unlock when the door is closed. If you want your door to remain locked when it closes, please purchase the 501 function.